



Pacific Modern Chair Assembly

1pcs Chair Seat Assembled (With Insert Nuts)

1pcs Chair Back Assembled

2pcs Chair Arms (with Insert Nuts)

6pcs 40mm Bolts

10pcs #8x1-1/2" Wood Screws

Assembly Instructions

1pcs Allen Key

2pcs Chair Front Legs (with Insert Nuts)

