



Requirements:

Adjustable Wrench Pipe Wrench Thread Tape Cordless Drill Phillips & Robertson Driver Bits

View the assembly process You Tube





To start the installation of the Glacier Plunge Tub, place the tub in your desired location.



Once you have the tub in the desired location, gently flip the tub on its side.

You can put down a blanket or towel to protect the side of the tub.



Unpack the hardware for the chiller (If Purchased) & drain assembly.



Wrap 3 layers of thread tape around the threads on both ends of the short pipe.





Thread the short piece of pipe into the drain hole from the bottom of the cold plunge tub.

This can be hand tight only at this time.



Screw the 90° elbow onto the short pipe.

Ensure it is tight and facing the hole in the frame on the side of the tub.



Wrap 3 layers of thread tape around the threads on both ends of the long pipe.



Thread the long piece of pipe into the elbow.

This can be hand tight only at this time.





Remove the plastic packaging and caps from the valve.



Screw the valve onto the end of the long pipe.



Using a pipe wrench or adjustable wrench, tighten the valve.

This will also tighten the long adapter into the elbow.

Have the handle of the valve facing in your desired position when tight.



Using a pipe wrench or adjustable wrench, tighten the garden hose connector (if ordered) onto the valve.

Manufactured by:



Cold Plunge Chiller Installation Instructions



Remove the plugs from the holes in the side of the tub.



Wrap 3 layers of thread tape around both ends of the threads on the 2 remaining long pipes and thread them into the holes on the side of the tub.

This only needs to be hand tight at this time.



Thread a quick connect onto each of the long pipes.

Tighten completely with a wrench.

Place the tub back in the proper position.



Cold Plunge Chiller Installation Instructions



Remove the chiller and all components from the box.



Insert the filter into the holder and screw onto the chiller.

Tighten with the provided filter tool.



Remove the covers on the inlet and outlet on the back of the chiller.



Install the inlet filter onto the inlet connection.



Cold Plunge Chiller Installation Instructions



Thread the Filter guard over the inlet filter.



Insert rubber washers into each end of the chiller hoses.



Screw the chiller hoses onto the inlet and outlet connections, Ensure they are tight.



Connect the other ends of the chiller hoses to the tub.

The hose from the outlet of the chiller will connect to the higher pipe of the tub and the hose from the inlet will connect to the lower pipe.

Manufactured by:



Cold Plunge Chiller Installation Instructions (Roll Up Cover)



To install the roll up cover, secure the cover brackets onto the preferred end of the plunge tub and secure with $2 - 2 \frac{1}{2}$ " (64mm) screws into each bracket.



Roll out the cover and align it to the edges of the tub.




Place a locking clasp onto one of the straps and pull it snug.

Once in desired position, remove the strap and secure the clasp with $2 - 1 \frac{1}{2}$ " (38mm) screws.



Repeat the above process for the remaining 3 straps.





Cold Plunge Chiller Installation Instructions (Roll Up Cover)



Use the provided key to lock and unlock the clasps.



It is recommended to keep cover locked when not in use to prevent unauthorized access to the plunge tub.



To open the cover, unclasp the straps and roll up the cover to sit on the cover supports.



Ensure the drain valve is closed, fill the tub with water and enjoy!

Manufactured by:



2 Tier Step Installation Instructions



To assemble the 2-tier step (if ordered), place the top step upside down and a stair support on top.



Ensure the stair support is flush at the back of the step and secure with $2 - 2 \frac{1}{2}$ " (64mm) screws.

Repeat for the second stair support.



Flip the assembled stairs right side up and then repeat the process to attach the bottom step.



Place the assembled stairs in the desired location next to the tub.





WARRANTY

Dundalk LeisureCraft Inc. warrants our Cold Plunge Tubs against defects in materials and workmanship under normal/residential use for a period of one (5) years, as applicable, from the date of receipt of the product by the original end-user consumer.

This warranty does not apply to normal wear and tear and/or natural weather conditions. This warranty does not cover misuse or negligence and the manufacturer and associated retailers are not liable for any injury or damage caused by the product.

This warranty is a parts only warranty and any service or labor costs would not be considered as part of the 5-year warranty.

Dundalk LeisureCraft Inc. warrants our Cold Plunge Chiller against defects in materials and workmanship under normal/residential use for a period of one (1) year, as applicable, from the date of receipt of the product by the original end-user consumer. This warranty does not apply to normal wear and tear and/or natural weather conditions. This warranty does not cover misuse or negligence and the manufacturer and associated retailers are not liable for any injury or damage caused by the product. This warranty is a parts only warranty and any service or labor costs would not be considered as part of the 1-year warranty.

In colder climates, when not in use, store Cold Plunge Chiller in a temperature-controlled setting to prevent freezing!

| Purchaser Name: _ | Date: |
|-------------------|-------|
| Purchased From: _ | |

